

WARNING!

Avoid Damage to Your Display


•••Read all instructions below•••

Pack and Unpack Carefully

Check for caught skins.



Check for twisted skins.



opening/closing instructions

Opening Xpressions™ Frame:

1. Take frame from box, Lay frame in front of you with the red hubs on the floor.
2. Make sure all skins are straight around the button holes
3. Take hold of the frame and carefully pull the frame up.
4. Snap all connectors into place.

Closing Xpressions™ Frame:

1. Unsnap all connectors
2. Slowly lower frame to the floor
3. Turn frame so front side is facing upward and tuck in all skins making sure they are straight at button holes.
4. For skins on the opposite side (back dimension) of the frame, turn frame over straighten as best you can and let the skins fall to one side.

Care Instructions

Machine wash cold or warm. Do not use bleach. Tumble dry low setting. Do not exceed 120°. Remove immediately to prevent wrinkling. Do not iron directly on logo, iron on backside of image Meets: NFPA#701

xpressions

xpressions **SNAP!**

AVOID DAMAGE TO YOUR DISPLAY, USE PROPER SET-UP PROCEDURE.


Included on some 3x3 frames, some 10
quad pyramid frames, all 4x4,
4x3, and projector frames

auto **X** lock

with manual release



MANUALLY RELEASE THE YELLOW AUTO
LOCK ON EACH SIDE **BEFORE** BREAKING DOWN



for added set-up
security some
xpressions SNAP! kits
are equipped with 2 yellow auto X locks. Large
frames or heavily skinned kits benefit from the
self locking manual release clips

The auto X locks keep your large or heavily skinned display up and stable. When it's time to break down your display **SIMPLY UNCLIP** both connectors, then break down the frames as you would normally!

The auto X locks do not affect the Quick Set-up of your display, they simply lock by themselves.

Watch for snagged skins, before and during set-up



PLEASE READ CAREFULLY BEFORE SETTING UP YOUR DISPLAY!

AVOID DAMAGE TO YOUR DISPLAY, USE PROPER SET-UP PROCEDURE.

SET YOUR DISPLAY UP ON A CLEAN SURFACE!

If no clean area is available do not allow graphics to drag on the floor. Use Two Person Set-up while keeping display off floor. Note: Dirty Fabric Graphics Can Be Washed with mild detergent low heat/hang to dry.



1. Unpack the display.



2. Place the frame on the floor - graphic side down - feet facing you.




3. Separate the frame slightly. Make sure graphics are not caught on the frame or connectors.




4. Locate center hubs.



5. Reach in midway to grab the frame poles.



6. With an even and controlled motion, extend your arms up and out until you hear the snap!



7. Enjoy your display!



AutoLock may come pre-installed on your display, **IMPORTANT** make sure to manually release the AutoLock before breaking down.




Break-down: To break-down your display, place your hands on the frame near the hubs and apply even pressure downward. This will release the magnetic connection of the hubs and the frame will collapse.

PLEASE READ CAREFULLY BEFORE SETTING UP YOUR DISPLAY!

xpressions **SNAP!**

AVOID DAMAGE TO YOUR DISPLAY, USE PROPER SET-UP PROCEDURE.

TWO PERSON SET.UP



For More Information Visit www.xpressions-snap.com / help and support / tutorials.